

1030i Button Layout



Phone Guide

- **Fixed Buttons**
 - **MSG:** Accesses message boxes
 - **Mute:** Mute the call so that the caller cannot hear your voice.
 - **Headset (icon):** If a headset is plugged in this button allows you to toggle between the headset and handset.
 - **Dir:** Assign or use assigned station speed dial numbers.
 - **Trans:** Transfer the current active call or access the Program menu while the phone is idle.
 - **DND (Do-Not-Disturb):** Blocks incoming calls. You can also activate Do-Not-Disturb while the phone is ringing - this terminates the call and the caller will get a busy tone.
 - **Hold:** Place a call on hold – the caller will receive on-hold music or comfort tones.
- **Menu button:** Access the settings for your phone, such as changing the font and display or changing configuration.
- **Volume button:** Adjust the Ring, Headset, Handset, and Speaker volume.
- **Speaker button:** Toggle the speakerphone On and Off during a call. The button will automatically illuminate when the phone is in menu mode.
- **Flexible buttons:** A line or feature can be assigned to these buttons.
- **LCD screen:** Phone interface for status, dialing directories, and text message information.
- **Soft Keys:** These buttons are interactive and have a changing function based on the phone's status.

The 1030i has 18 programmable keys across 3 pages

Dealing with calls

Using the Phone Book Directory

Access the stored
telephone numbers in your system

Press the **Directory** button followed by one of the following options:

- 1 - **Station Speed**
- 2 - **Group Speed**
- 3 - **Station Name**

Once selected you can then use the navigation keys to scroll through the list. To alpha dial, press the button showing the letter you wish to dial – e.g. press 2 for the letter B. Then, press the button with the second letter. The system will show all matches. Then press **OK** to dial the number.

Accessing your Voicemail

Press the Message button followed by one of the following options:.

- 1 – accesses messages to give an internal user a call back
- 2 – to access your voicemail
- 3 – to sort internal messages

If you do not know your pin, contact your system administrator

Quick access call tools

Listening to Voicemail (Options)

Lift the handset

Press the **Dir** button

Select; (1) **Station Speed** --> (2) **Group Speed** --> (3) **Station Name**

For options 1 & 2, follow the on-screen instructions.

For option 3, scroll through names or search using the key pad

Voicemail

Answering an Incoming Call	Lift the handset. To answer a call on another extension that is programmed to one of the phones 5 flex keys, press the flashing flex key before lifting the handset. You can also set flex keys for call pick-up and group call pick-up.
Making an External Call	Lift the handset then press a free flex key allocated to a line, or dial 9 to pick up an outside line. Once you have an outside line, dial your number.
Making an Internal Call	Lift the handset. Dial the extension Number or press the flex key assigned to the contact.
Rejecting a Call	Press the DND button when a call comes in.
Placing a call on hold	Press the Hold button. To reconnect the call, press the Green flashing flex key.

Parking a call

Parking a call	To park an active external call, press Transfer , dial the park code (i.e. #601 for Park 1), and hang up to return to idle. To retrieve a parked call, lift the handset and dial the park code.
Camp On (Call Waiting)	When dialling an extension that is engaged, the Camp On feature allows the station to be notified that there is a call waiting. Press your assigned flex key to initiate camp on.

Transferring a call

Transferring a Call	During an active call, press either the Transfer button or the TRANS soft key. Dial the extension number, external number or press the programmed flex key. Either speak to the recipient to announce the call, or simply hang up to complete the call transfer.
Returning to Caller from a Transfer	If you are unable to transfer the call, press the Green flashing flex key or the transfer key again to return to the caller.

Redialling a number

Call Redial	Press the Redial soft key.
-------------	-----------------------------------

Features

Do-Not-Disturb Makes your extension unavailable	Press the DND key to activate. Press the DND key again to deactivate. Please note that this is not available on the attendant handset.
Ad Hoc Conference Calls 3 way calling	To call the first party, follow "Making an External/internal Call" above for instructions. Once connected press the assigned flex key Call the second party (as above). Once connected, press the assigned flex key twice to connect the calls.
Programming Call Forward (Routes your calls to another extension/group/speed dial) All these features will override your voicemail functions.	Dial 501 (or assigned feature code) then select one of the following options: 1 - Unconditional Forward (forwards all calls instantly) 2 - Busy Call Forward (Only forward calls when you are on the phone) 3 - No Answer Call Forward (Only forwards calls if you don't answer) 4 - Busy / No Answer Call Forward (Mix of 2 & 3) Dial the extension number To disable all call forwarding, dial 502 (or assigned feature code)

